

900 Series Aluminum retained instructions

CHANGE NON-KEY RETAINED TO KEY RETAINED

1



prepare Allen key and grub screw

2



fix the grub screw on the screw hole of the cam to become key retained

INSIDE DETAILS

