

Travel Lock - Instruction Sheet

7400

The new SearchAlert re-settable combination padlock by Prestolock® offers two unique innovations in luggage security:

TO RESET Searchalert window:

Padlock is preset to 0-0-0. Turn wheels to this combination. Pull up on shackle to open. This Travel Lock product is preset on Green at the factory. If a secured access device was used to open your SearchAlert combination lock, the color of the Security Window would change from Green to Red. To reset your SearchAlert Security Window back to Green, follow these simple steps:

- **Step #1:** Set the dials to the correct combination and pull up the shackle.
- **Step #2:** Turn the shackle 180 degrees, and push shackle in. The Security Window should change color from Red to Green.
- Step #3: Pull up the shackle and the SearchAlert is ready for full use.

OPERATING INSTRUCTIONS

This Travel Lock product is preset at the factory to open at 0-0-0. To reset your SearchAlert combination lock to open on your own combination follow these simple steps:

- **Step #1:** Set the dials to 0-0-0 and pull out the shackle.
- Step #2: Turn shackle halfway around (180 degrees) and push in.
- **Step #3:** Hold shackle depressed and turn 90 degrees (¼ turn) in either direction.
- **Step #4:** Set the dials to your own combination. Memorize the combination.
- **Step #5:** Without moving the dials, return the shackle to the 180 degree position. Pull out shackle and turn it 180 degrees.
- **Step #6:** Push shackle in, it should not lock. Push shackle in and turn one or more dials, the shackle should lock.
- **Step #7:** To test, turn dials to the new combination, pull shackle open. Combination can only be changed when the lock is in the open position. Follow steps 2 through 6.



